




WINDOW SILL PROFILE



PREPARATION

- Determine and mark the position (bubble level, chalk line).



ANGLED SECTION

- Cut the angled section to size for the right side of the window sill profile (saw, mitre box or electric mitre saw).



- Lightly sand the cut edges and the edges with sandpaper or cutter.



- Remove the sawdust with a damp sponge.




- Using a cartridge gun, generously apply the DOMOSTYL® HYBRID adhesive in a continuous bead on the backside (see GLUE CONSUMPTION).



- Install angled section.



- Turn right-angled window sill profile with the lower edge upwards and mark the appropriate length on the lower edge.



WINDOW SILL PROFILE ANGLED ON BOTH SIDES

- After installation, the window sill profile should be sufficiently protrude.



- Cut the left side angle of the window sill profile to size.



- Fit the left side angle, remove excess adhesive with a cloth soaked in turpentine substitute.

ANGLED WINDOW SILL PROFILE



- Apply DOMOSTYL® HYBRID adhesive to the wiped adhesive surfaces of the angled window sill profile as a continuous bead, diameter 10mm, all around (see GLUE CONSUMPTION).



- Fit the window sill profile, if necessary, use nails to prevent the window sill profile from slipping.



- Install professionally the metal or stone window sill.

FRAME PROFILES



- Position the frame profile (let it protrude by approx. 2mm) and mark the position (spirit level).



- Cut the frame profile to fit the mitre (saw and mitre box or electric mitre saw).



- Apply DOMOSTYL® HYBRID adhesive to the back of the profile all around as a continuous bead (diameter 10mm) (see GLUE CONSUMPTION).



- Apply DOMOSTYL® HYBRID adhesive to the gluing surfaces and mitre cuts (liberated from sawdust). The surface should be completely covered with the adhesive. The adhesive joint must be formed so that it has a width of 3 mm after completion.



- Install frame profiles, butt joints and mitre joints with DOMOSTYL® HYBRID adhesive. After drying (approx. 24 hours), fill the adhesive joints again with DOMOSTYL® HYBRID adhesive.



- Joint professionally with DOMOSTYL® HYBRID adhesive the frame profiles including the protruding edge in the area of the window jam.



- After the joints have dried (approx. 24 hours), smooth the window reveal along the protruding edge of the frame profile, which has been grouted with DOMOSTYL® HYBRID adhesive, with a facade filler.



- After drying, coat the facade profiles 2 times with pure acrylate based facade paint (see FINISH).